

Husqvarna RVL 200
Husqvarna RVL 300

Pièces de rechange

Spare parts

Ersatzteile

Piezas de repuesto

Ricambi

Onderdelen


Reservdelar

Peças sobresselentes

115036420	A	MANUAL, OM
155036520	A	MANUAL, IPL
502619501	B	ENGINE GX25 HUSQVARNA EU
502619502	B	ENGINE GX25 HUSQVARNA AUS
502620401	B	ADJUSTING SCREW
503200003	B	SCREW HEX 5x12
505022501	C	STICKER, BY HONDA
505022401	A	STICKER, SECURITY
537311201	C	COVER
537311301	C	MUFFLER GUARD
537311401	C	AIRCLEANER
537311501	C	STARTER
537311601	C	BUMPER
542043735		OIL, 10w30
543041396	A	SPARE BEAM 2M, WITH HANDLE
543041397	A	SPARE BEAM 3M, WITH HANDLE
543043961	A	U, OUTSIDE
543043966	A	HANDLE
543043967	B	TRAINER
543044816	A	PIN CLIP D/8 LG 45
543044864	A	RIVET, STAINLESS 4.8 x 9
543045292	A	SWITCH
543045342	A	SPRING COLLAR
543045642	A	LEVER 17270 D25
543045787	A	STICKER, NOISE 106DB
543045893	A	KEY 17
543045980	A	RUBBER SILENT BLOCK 40 x 28
543045981	B	RUBBER SILENT BLOCK 20 x 20
543046031	A	FEET PAD D35
543046041	A	PAD D25
543046255	A	RUBBER BLOCK 125/30/30
543069729	A	ARM - DRILLING
543072495	A	STICKER, DO NOT LIFT
543075941	B	MACHINED RVL BLOCK
543075944	B	VIBRATION DAMPER 20x30 GM 6x15
543076971	B	VIBRATING AXLE GX 25
543077017	B	WIRE LENGHT 160MM RVL
543077018	B	WIRE LENGHT 240MM RVL
543077019	B	WIRE SLEEVE 400MM RVL
543077020	B	INNER CABLE LENGHT 500 MM
543077386	B	VIBRATING BOX ASSY
543077644	A	HANDLE CARRY
543082378	A	STIRRUP
543082379	A	MOTOR SUPPORT
543850017	B	NYLON COLLAR 5x250
722781803	A	RIVET 3,2
725245171	A	Screw Hex 8x20-FT
725245951	A	Screw Hex 8x40
725248571	A	Screw Hex 10x10-FT
725250151	A	Screw Hex 10x50
725250251	A	Screw Hex 10x55
725250551	A	Screw Hex 10x70
725251951	A	Screw Hex 10x150
725536401	A	Screw Inhex 6x10
731231601	B	Nut, M6
731231801	A	Nut, M8

731232001	A	Nut, M10
732211601	B	Nut, Nylock M6
732252001	A	Nut, Nylock M10
734115201	B	Washer M6
734115441	B	Washer, Large M6
734117201	A	Washer M10
735217301	A	Washer, Lock M10
735314010	B	Circlips for bore Ø47
738220119	B	BALL BEARINGS 6201 2 RS
738220419	B	BALL BEARINGS 6204 2 RS

R.V.L



543 077 644 (1)
 543 045 292 (1)
 543 045 642 (1)

722 781 803 (2)

725 248 571 (1)

735 217 301 (1)

725 250 551(1)

543 082 378 (1)

731 231 801 (1)

725 248 571 (2)

735 217 301 (2)

543 045 980 (1)

725 251 951 (2)

734 117 201 (2)

725 245 171 (4)

543 082 379 (1)

725 248 571 (2)

735 217 301 (2)

731 232 001 (2)

* 543 044 864 (1)

*543 045 342 (1)

* 2m

* 3m

*Compl 543 041 396 (2m)

*Compl 543 041 397 (3m)

543 046 041 (2)

734 117 201 (2)

505 022 401 (1)

543 072 495 (1)

543 045 787 (1)

732 252 001 (1)

734 117 201 (2)

725 250 251 (1)

543 069 729 (1)

725 250 151 (1)

725 245 951 (1)

543 044 816(1)

*543 043 966 (1)

*543 046 031 (1)

725 536 401 (2)

543 043 961 (1)

735 217 301 (1)

725 248 571 (1)

735 217 301 (2)

543 045 980 (2)

*543 046 255 (2)


543 045 893 (1)




115 036 420 (1)



115 036 520 (1)



A



502 620 401 (EU-US)(1)
502 620 402 (AUS) (1)

543 077 020(1)

732 251 601(1)


543 077 018(1)

734 115 201(1)

543 850 017(2)

543 077 017(1)

543 077 019(1)



503 200 003 (1)

502 619 501 (EU)(1) [C]
502 619 502 (AUS)(1) [C]

*543 043 967(1)

*731 231 601(1)

*734 115 441(1)

*731 231 601(1)

*543 075 944(4)

*543 045 981(1)

*734 115 441(2)

*734 115 441(2)

*543 075 941 (1)

*731 231 601(4)


*738220119(1)

*543 076 971(1)

*738 220 419(1)

*735314010(1)

*Compl 543 077 386





www.husqvarnacp.com