

ILLUSTRATED PARTS LIST

BRAND: McCULLOCH

ROTARY LAWN MOWER

MODEL NUMBER: M53-190ER

MFG. ID. NUMBER: 96141026603


This exploded view diagram illustrates the assembly of a snowblower. The components are numbered 1 through 103. The main body (1) is the central housing. The engine (100) is mounted at the top left. The auger assembly (13, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103) is located at the bottom. The diagram shows the relationship between the main body, the engine, the auger assembly, and the chute assembly. Dashed lines indicate the assembly path for each component.

McCULLOCH ROTARY LAWN MOWER - - MODEL NUMBER M53-190ER (MFG. ID. NUMBER 96141026603)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	580 63 87-02	Handle, Upper	38	- - -	Engine, Briggs & Stratton, Model Number 122T05-1615-H1 (Order parts from B&S)
2	532 19 60-05	Handle, Lower	39	581 00 29-05	Bag, Grass Catcher
3	532 40 54-16	Spring, Rear Door, RH	40	532 41 19-51	Frame, Grass Bag
4	581 90 21-01	Guide, Rope	41	532 18 21-66	Decal Danger
5	581 91 26-01	T-Knob	42	817 06 04-10	Screw, Self Tapping
7	532 19 15-74	Bolt, Handle 5/16-18 x 1.75	45	532 19 13-41	Mulcher Door
8	532 19 19-38	Knob, Handle	46	532 19 12-10	Discharge Deflector
9	587 68 93-03	Control Bar, Molded	47	532 08 83-49	Nut, Hex
10	532 18 88-21	Bolt, Carriage	48	532 42 90-01	Belt Keeper
11	532 75 11-53	Nut, Hex, with Lockwasher Insert 5/16-18	61	532 16 34-09	Screw, Hi-Lo Thread #12 x 5/8
12	532 05 17-93	Cotter, Hairpin	62	532 40 80-02	Box, Battery
13	532 40 54-15	Spring, Rear Door, LH	63	532 18 95-89 EU	Battery
16	532 40 88-88	Rear Door Assembly	64	581 82 65-01	Charger, Battery
17	532 18 41-93	Bolt, Rear Door	65	532 44 66-94	Screw
18	532 19 81-70	Plug, Mulcher	66	587 93 43-01	Electric Start Switch Assembly (Includes Switch Housing, Switch and Wiring Harness)
19	532 40 97-33	Kit, Lawn Mower Housing Assembly	67	580 91 52-03	Button, Start
20	532 19 40-29	Handle Bracket Assembly, LH	68	501 80 11-02	Wiring Harness
21	532 19 40-31	Handle Bracket Assembly, RH	69	532 42 59-37	Fuse, 40 Amp
22	532 42 88-67	Screw, Hex Washer Head	96	532 19 79-91	Clip, Cable
23	532 16 31-83	Bolt, Hex Head 5/16-18 x 5/8	100	580 27 36-01	Shroud, Engine, McCulloch
24	873 80 05-00	Nut, Hex, with Lockwasher Insert 5/16-18	101	581 79 50-01	Mounting Screw, Engine Shroud
25	532 16 13-33	Baffle, Side	102	532 44 66-95	Nut, Hex, with Lockwasher Insert 1/4-20
26	532 16 34-09	Screw, Hi-Lo Thread #12 x 5/8	103	532 42 81-24	Fastener, Push
29	532 44 03-86	Cable, Operator Presence	- -	532 18 21-91	Warning Decal (not shown)
30	532 42 11-76	Adapter, Blade	- -	115 62 90-20	Operator's Manual, European
31	532 19 93-77	Blade, 21"	- -	115 62 90-10	Operator's Manual, Scandinavian
32	532 85 10-74	Washer, Hardened	- -	115 62 90-50	Operator's Manual, East Bloc
33	532 85 02-63	Lockwasher, Helical Spring 3/8	- -	115 62 90-40	Operator's Manual, Baltic
34	532 85 10-84	Screw, Hex Head 3/8-24 x 1.38	- -	115 80 63-53	Operator's Manual, Ukrainian
37	532 15 04-06	Bolt, Engine			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.



McCULLOCH ROTARY LAWN MOWER - - MODEL NUMBER M53-190ER (MFG. ID. NUMBER 96141026603)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	585 04 08-01	Drive Control Assembly (Includes Cable)	28	812 00 00-58	E-Ring 7/16
2	585 12 31-02	Control Bar, Drive	29	581 84 04-01	Cover, Dust, Wheel
11	532 40 65-58	Spring, Return	31	532 40 48-45	Pawl, Drive
13	532 41 92-13	Gearcase Assembly, Complete	32	581 68 55-05	Wheel & Tire Assembly, Rear, Driven
14	532 40 57-03	Pulley, Driven	33	532 40 91-48	Nut, Hex, Flangelock
15	532 08 83-48	Washer, Flat 3/8	34	532 85 12-26	Washer
16	532 40 71-47	Rod, Connecting	35	532 41 09-22	Shaft Assembly, Rear
17	532 40 96-16	Spring, Extension	36	532 41 09-33	Shaft Assembly, Front
18	532 41 88-66	Spring, Selector	37	532 16 14-63	Retainer, Front Shaft
19	532 19 00-69	Knob, Selector Spring	38	532 16 34-09	Screw, Hi-Lo Thread #12 x 5/8
20	812 00 00-22	E-Ring 7/8	39	532 40 70-59	Bolt, Shoulder, Semi-Gimlett Point
21	532 40 48-38	Bearing Assembly	40	581 00 94-05	Wheel & Tire Assembly, Front
23	532 16 45-55	Retainer, Drive Assembly	41	532 40 48-35	Pinion Assembly
24	817 06 04-10	Screw, Self-Tapping, Hex Head 1/4-20 x 5/8	42	532 19 74-80	O-Ring
25	532 43 26-70	Drive Cover Assembly (Includes Mounting Screw and Pushnut)	44	580 36 46-04	V-Belt
			47	532 06 77-25	Washer 1/2 x 1-1/2 x .134
			50	532 41 37-22	Belt Keeper

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.